System-Integration Application Pump OptiSpray AP01




Your global partner for high quality powder coating

OptiSpray AP01

Key Features

- Inline concept
- Single chamber
- Superior technology
- Easy integration



Key Benefits

- 15% powder savings
- Application quality
- Easy color change
- Easy maintenance



System Integration OptiSpray AP01


OptiCenter OC03

+ OptiSpray AP01






Overview OptiCenter OC03




Overview OptiCenter OC03





Overview OptiCenter OC03



Key Features OptiCenter OC03

Excellent coating quality

- Short suction tubes
- Continuous mix of fresh and recovery powder
- Gentle powder conveying

Quick color change

- Automated cleaning procedure
- Efficient powder management
- Closed loop powder circuit


Compact design

- Electrostatic + powder management
- Flexible variety of configuration






OptiCenter OC03: Pumps Integration



OptiCenter OC03: Pumps Integration



OptiSpeeder (Cross section)


- Closed powder hopper
- Volume for 5 kg of powder
- up to 24 Guns

Precise powder flow

- constant powder level
- short suction tubes
- \rightarrow Excellent for quick response




OptiCenter OC03: Pumps Integration




Wiring OptiSpray AP01


Wiring of OptiSpray AP01

- Powder hose (green)
- Pneumatic hoses (blue)
- Electro cable (red)










Touch Panel 5,7


Ergonomic design,


integrated into the operating area

- **Easy** and **intuitive** operation concept
- Reliable data handling
 Back-up with compact flash card
 Remote access by Gema support
- OptiCenter standard software











OptiSpeeder / OptiSpray AP01

- 5kg powder hopper capacity
- Powder level control
- Fresh and recovery powder pumps connections








Powder Cone

- Fresh powder bag cone (up to 25 kg)
- Movable for powder hopper emptying
- Fluidizing **powder suction tube**
- Fresh powder (FP) pump connection
- Recovery powder (RP) pump connection




OptiSpeeder Cleaning






OptiSpeeder Cleaning



Powder hopper cleaning


- Fluid plate cleaning
- OptiSpray AP01 plus suction tube cleaning





Maintenance OptiSpray AP01

1. Remove covers






06.06.2017 18

Maintenance OptiSpray AP01


2. Remove pump head





Maintenance OptiSpray AP01

3. Easy replacement of the filter chamber and pinch valves



OptiCenter OC03 / Summary



Customer Benefits

- Excellent coating quality
 - \circ Short suction tubes
 - Continuous mix of fresh and recovery powder
 - o Integrated quality sieve solution
- Quick color change
 - Sealed powder circuit
 - Automated cleaning procedure
- Compact design
- Ergonomic and intuitive interface
- Easy maintenance

Summary Comparison

<u>C(</u>

CONFIDENTIAL, FOR INTERNAL USE ONLY!	COMPARISON	CUSTOMERS BENEFITS				
	Gema	Application	Powder	Color	Integration &	
	OptiCenter	Quality	Savings	Change	Maintenance	
		CONTROL CONTROL CONTROL CONTROL	\$ 5		×	
Pumps Integration						
Solution Overview						
Operating area with air extraction		\odot		\bigcirc	\odot	
Space saving design						
Ergonomic user interface		\odot	\odot	\bigcirc	\odot	
Flexibility of use			\odot			
Integrated high quality sieve		\odot		\odot	\odot	
Integrated fresh powder supply	٢			\odot		
Pumps Integration						
Compact solution	\odot				\odot	
Ideal pumps positioning	\odot	\odot	\odot		\odot	
Short suction tubes	\odot	\odot	\odot			
Automatic cleaning pumps				٢		



Summary Comparison

CONFIDENTIAL, FOR INTERNAL USE ONLY!	COMPARISON	CUSTOMERS BENEFITS				
	Gema	Application	Powder	Color	Integration &	
	OptiCenter	Quality	Savings	Change	Maintenance	
		ALTER	\$ 5		×	
Pumps Integration						
Powder Hopper			•	•		
Small hopper concept		O	\odot	\odot	\odot	
Sealed powder circuit		0		\odot	Ü	
Continuous mix of fresh + recovery powder		۲				
Automatic hopper cleaning						
Color change process						
Quick color change	٢			\odot		
Easy color change process			•	\odot		
Reduced contamination risk	٢	٢	\odot			
Application quality						
Ideal powder fluidization		\odot	٢			
Protection from contamination		\odot	٢			
Ideal powder delivery to the guns	۲	\odot	\odot			
Ideal powder sieving	۲	\odot	\odot			
Ideal powder sieving		٢	٢			



Thank you very much for your attention!



Your global partner for high quality powder coating